


\* Please understand key indicators & functions at the first operation.

### FRONT PANEL & KEY FUNCTIONS



Key Name	Symbol	Descriptions
Reset Key	(Z)	1. Press this key to enable the reset function & reset indicator (Z) is light; press this key again to disable the reset function & reset indicator (Z) is dark.
Enter Key & Save Key	ENT	1. In the measuring status, press this key can enter to parameter pages. 2. In the parameter setting, press this key can save the value & go to next parameter.
Shift Key	AL	1. In the parameter setting , press this key can move the cursor left.
Up Key & Display Span Adjusting Key	↑	1.In the measuring status, press this key for 3 sec can enter to display value adjustment of "SPAN" 2. In the parameter setting, press this key can increase the digits.
Down Key & Display Zero Adjusting Key	↓	1.In the measuring status, press this key for 3 sec can enter to display value adjustment of "ZERO" 2. In the parameter setting , press this key can decrease the digits.

- \*\*1. The following block charts are parameters codes, parameter codes & parameters will alternate flashing if the parameters can be modified.
- 2. To modify the parameters, please press , and press ENT to save the parameters after the modification.
- 3. Please don't forget the new pass code after modification.
- 4. In any pages, press & , or don't press any keys for 2 minutes that will back to measuring status.

### GENERAL MODE OPERATING PROCEDURES

Block Charts	Display	Descriptions	Default
		<b>Display: SPAN Adjustment</b>	
	Measuring Status	Present value for measurement.	
	Display Span Adjustment (dSPAn)	Press  to select adjusting speed rate, press   to modify the span value. PS: To use this function to adjust the real span value.	
		<b>Display: ZERO Adjustment</b>	
	Measuring Status	Present value for measurement.	
	Display (dZero) Adjustment (dZero)	Press  to select adjusting speed rate, press   to modify the zero value. PS: To use this function to adjust the real zero value.	

# ENGINEER LEVEL OPERATING PROCEDURES

Block Charts	Display	Descriptions	Default
	Measuring Status	Present value for measurement	
	Pass Code (P.Cod)	Press  to enter pass code. Pass code is correct that will enter to parameter groups. Pass code is wrong that will back to measuring status.	00000
	System Setting Page (SYS)		
	Control DI 1 Setting (di-1)	Press  to select control DI parameters (2DSP, Z, MAX, HD); terminal 5 & 7 shorts. EX: D/I 1 is set for (AZ), when terminal 5 (DI1) & 7 (COM) shorts, the reset indicator (Z) will flash & the value will be reset 0. (Default: AZ: D/I 1 reset)	RP
	Control DI 2 Setting (di-2)	Press  to select control DI parameters (2DSP, Z, MAX, HD); terminal 6 & 7 shorts. EX: D/I 1 is set for (2DISP), when terminal 6 (DI2) & 7 (COM) shorts, the display value 2 indicator (DISP2) will flash & show 2nd value. (Default: MAX: D/I 2 Max value)	RR
	Decimal Point 1 Setting (dP1)	Press  to select decimal point (0, 1, 2, 3, 4) EX: if the value shows "0.00" that means the decimal point is 2 digits.	Customers specify
	Display Low Scale 1 Setting (dSPL1)	Press  to modify display low scale for the input signal zero value. EX: If the input signal is 4~20mA; 4mA is shown display 0.00, this parameter must be set for 000.00.	Customers specify
	Display Hi Scale 1 Setting (dSPH1)	Press  to modify display high scale for the input signal span value. EX: If the input signal is 4~20mA; 20mA is shown display 100.00, this parameter must be set for 100.00.	Customers specify
	<b>The following steps are only available when DI1 or DI2 is set for "2nd Display".</b>		
	Decimal Point 2 Setting (dP2)	Press  to select decimal point (0, 1, 2, 3, 4) EX: if the value shows "0.00" that means the decimal point is 2 digits.	Customers specify
	Display Low Scale 2 Setting (dSPL2)	Press  to modify display low scale for the input signal zero value. EX: If the input signal is 4~20mA; 4mA is shown display 0.00, this parameter must be set for 000.00.	Customers specify
	Display Hi Scale 2 Setting (dSPH2)	Press  to modify display high scale for the input signal span value. EX: If the input signal is 4~20mA; 20mA is shown display 100.00, this parameter must be set for 100.00.	Customers specify
	Display Average Setting (AvG)	Press  to modify display average (1~99) PS: Please use this function for stable display value when input signal is unstable.	00005
	Display Low Cut Settingn(LCUT)	Press  to modify display low cut to 0(0~99)	00000
	Pass Code Setting (CodE)	Press  to modify pass code(0~19999) PS: Please don't forget the new pass code after modification.	00000
	Key Lock Setting (LoCK)	Press  to lock the keys, using key lock function only can view the parameters, but cannot modify any values. PS: no(unlock), YES("ENT" unlock, others lock)	non

## Error Code of Self-Diagnosis

Display	Descriptions	Display	Descriptions
, oFL	Input signal is over 120% of input range.	doFL	Input signal is over display range (99999)
-, oFL	Input signal is under -20% of input range.	-doFL	Input signal is under display range (-19999)
RdEr	Input signal is over 180% of input range or meter error.	E-00	EEPROM reading /writing suffers the interference (about 1 million times)

\*\*Please check the wiring connection is correct first, if the problem still exist, please return the meter to the factory.

# CALIBRATION OPERATING PROCEDURES

Display	Descriptions	Default	
	Measuring Status Press ENT &  together for 3 sec  Input Low Scale Calibration (inLo) Input Hi Scale Calibration (inHi)  System Setting Page (SYS)	Present value for measurement Press ENT &  together for 3 sec will enter to calibration operating procedures.  1. Input standard low scale signal. 2. Press  to calibrate input low scale. (LED flashing)  1. Input standard hi scale signal. 2. Press  to calibrate input hi scale. (LED flashing)  1. Finish calibration operating procedures will enter to system setting group. 2. Press  to back to measuring status.	

**Warning: Calibration of this meter requires a standard signal with 0.01% accuracy or better and an external meter with 0.005% accuracy or better.**