


* Please understand key indicators & functions at the first operation.

FRONT PANEL & KEY FUNCTIONS



Key Name	Symbol	Descriptions
Reset Key	(Z)	1. Press this key to enable the reset function & reset indicator (Z) is light; press this key again to disable the reset function & reset indicator (Z) is dark.
Enter Key & Save Key	ENT	1. In the measuring status, press this key can enter to parameter pages. 2. In the parameter setting, press this key can save the value & go to next parameter.
Shift Key & Alarm Setting Key	\triangleleft	1. In the measuring status, press this key for 3 sec can enter to alarm setting page (The selecting digit will be flashed) 2. In the parameter setting, press this key can move the cursor left.
Up Key	\triangleup	1. In the parameter setting, press this key can increase the digits.
Down Key & A/O Adjusting Key	\triangledown	1. In the measuring status, press this key for 3 sec can enter to analog output adjustment. 2. In the parameter setting, press this key can decrease the digits.
Combination Key (Linearization)	ENT + \triangleleft	1. In the measuring status, press the key for 3 sec can enter to 20 points linearization setting.
Combination Key (Display Adjustment)	\triangleleft + \triangleup	1. In the measuring status, press the key for 3 sec can enter to 20 points display adjustment setting.

- **1. The following block charts are parameters codes, parameter codes & parameters will alternate flashing if the parameters can be modified.
- 2. To modify the parameters, please press $\triangleleft\downarrow\triangleup\downarrow$, and press ENT to save the parameter after the modification.
- 3. Please don't forget the new pass code after modification.
- 4. In any pages, press $\triangleup\&\triangledown$, or don't press any keys for 2 minutes that will back to measuring status.

GENERAL MODE OPERATING PROCEDURES

Block Charts	Display	Descriptions	Default
Power ON	10000	Measuring Status Present value for measurement	
Press $\triangleleft\downarrow\triangleup\downarrow$ for 3 sec	RL 1	Alarm 1 Setpoint (AL1) Press $\triangleleft\downarrow\triangleup\downarrow$ to modify alarm 1 setpoint.	00000
Press ENT	RL 2	Alarm 2 Setpoint (AL2) Press $\triangleleft\downarrow\triangleup\downarrow$ to modify alarm 2 setpoint.	00000
Press ENT	RL 3	Alarm 3 Setpoint (AL3) Press $\triangleleft\downarrow\triangleup\downarrow$ to modify alarm 3 setpoint.	00000
Press ENT	RL 4	Alarm 4 Setpoint (AL4) Press $\triangleleft\downarrow\triangleup\downarrow$ to modify alarm 4 setpoint.	00000
	10000	Analog Output: "ZERO" & "SPAN" Adjustment	
Press $\triangleleft\downarrow\triangleup\downarrow$ for 3 sec	RPEro	Measuring Status The following steps are only available for analog output.	
Press ENT	RSPAn	A/O Zero Adjustment (AZEro) Press \triangleleft to select adjusting speed rate, press $\triangleup\downarrow$ to modify the A/O zero. PS: To use this function to adjust the real A/O zero.	00000
Press ENT		A/O Span Adjustment (ASPA) Press \triangleleft to select adjusting speed rate, press $\triangleup\downarrow$ to modify the A/O span. PS: To use this function to adjust the real A/O span.	00000

Remark: 1. There are 3 parameter groups of "System Setting Group(SYS)", "Alarm Setting Group(roP)", "Analog Output Setting Group (AoP)" for modification.
2. Press \triangleleft to select each group page, and press ENT to enter each group or parameter page for modification or saving the parameters.
3. Some of optional functions of parameter pages still exist, but the functions are disable.

PROGRAMMING MODE OPERATING PROCEDURES

Display	Descriptions	Default
Power On	Parameter Group Setting Procedures	
10000	Measuring Status Present value for measurement	
P.Cod	Pass Code (P.Cod) Press $\triangleleft\downarrow\triangleup\downarrow$ to enter pass code.	00000
P.Code Correct	Pass code is correct that will enter to parameter groups. Pass code is wrong that will back to measuring status.	
NO		
YES		
545 (SYS)		
roP (roP)		
RoP (AoP)		
System Setting Group		
Alarm Setting Group		
A/O Setting Group		

Display		Descriptions	Default
System Setting Page (SYS)		System Setting Group Procedures	
Press ENT ↓	545	Decimal Point Setting (dP)	Customers specify
Press ENT ↓	dP	Press $\triangle\downarrow$ to select decimal point (0, 1, 2, 3, 4). EX: if the value shows "0.00" that means the decimal point is 2 digits.	
Press ENT ↓	SdP	Scale Decimal Point Setting (SdP)	Customers specify
Press ENT ↓	SCALE	Press $\triangle\downarrow$ to select scale decimal point (0, 1, 2, 3, 4). EX: if the value shows "0.00" that means the decimal point is 2 digits.	
Press ENT ↓	RuG	Display Scale Setting (SCALE)	0000 1
Press ENT ↓	LCUE	Display Average Setting (AvG)	00005
Press ENT ↓	Code	Press $\triangle\downarrow$ to modify display average (1~99). PS: Please use this function for stable display value when input signal is unstable.	
Press ENT ↓	LCUT	Display Low Cut Setting (LCUT)	00000
Press ENT ↓	5qrE	Pass Code Setting (CodE)	00000
Press ENT ↓	LoCk	PS: Please don't forget the new pass code after modification.	
Press ENT ↓	5qrE	Root Square Setting (SqrT)	no
Press ENT ↓	LoCk	Press $\triangle\downarrow$ to select root square setting (NO or YES)	
Key Lock Setting (LoCk)		Press $\triangle\downarrow$ to lock the keys, using key lock function only can view the parameters, but cannot modify any values. PS: no (unlock), YES ("ENT" unlock, others lock).	no
Alarm Setting Group Procedures			
The following steps are only available for alarm output.			
Press ENT ↓	roP	Alarm 1 (ACT1)	Press $\triangle\downarrow$ to modify alarm value that is \geq (Hi) or $<$ (Lo) for alarm action.
Press ENT ↓	ACT1	Alarm 2 (ACT2)	PS: 1. There are 4 alarms output optional.
Press ENT ↓	ACT2	Alarm 3 (ACT3)	2. This page is exist without alarm output, but the function will be disabled.
Press ENT ↓	ACT3	Alarm 4 (ACT4)	3. Press ENT to save the value and go to the next parameter.
Press ENT ↓	HYS1	Hysteresis 1 (HYS1)	H
Press ENT ↓	HYS2	Hysteresis 2 (HYS2)	
Press ENT ↓	HYS3	Hysteresis 3 (HYS3)	
Press ENT ↓	HYS4	Hysteresis 4 (HYS4)	
Press ENT ↓	dEL1	Delay Time 1 (dEL1)	00000
Press ENT ↓	dEL2	Delay Time 2 (dEL2)	
Press ENT ↓	dEL3	Delay Time 3 (dEL3)	
Press ENT ↓	dEL4	Delay Time 4 (dEL4)	
Press ENT ↓	5b	Alarm Start Band Setting (Sb)	00000
Press ENT ↓	Sdt	Alarm Start Band Time Setting (Sdt)	00000
Press ENT ↓		Press $\triangle\downarrow$ to modify the value (-99~+99), if the display value don't over this range; the alarm will not be act.	
Press ENT ↓		Press $\triangle\downarrow$ to modify the value (0~99 sec), if the display value reach alarm start band value; the alarm will be act after this value (sec). (The function is used with "Sb" function.)	

Display		Descriptions	Default		
A/O Setting Group Procedures					
A/O Setting Page (AoP)	roP	The following steps are only available for analog output.			
Press ENT ↓	PoLAr	A/O Polarity Setting (PoLAr)	no		
Press ENT ↓	AnLo	A/O Low Scale Setting (AnLo)	00000		
Press ENT ↓	AnHi	A/O Hi Scale Setting (AnHi)	99999		
Error Code of Self-Diagnosis					
Display	Descriptions				
1_oFL	Input signal is over 120% of input range.				
-1_oFL	Input signal is under -20% of input range.				
AdEr	Input signal is over 180% of input range or meter error.				
doFL	Input signal is over display range (99999)				
-doFL	Input signal is under display range (-19999)				
E-00	EEPROM reading/writing suffers the interference (about 1 million times).				
**Please check the wiring connection is correct first, if the problem still exist, please return the meter to the factory.					

	Display	Descriptions	Default
	20 Points Display Adjustment		
	 Press  &  together for 3 sec		
Measuring Status	Present value for measurement Press  &  together for 3 sec will enter to 20 points display value adjustment.		
No.1 Display Value Setting (dSP01)	Press  &  to modify No. 1 display value (-19999~99999)	99999	
No.2 Display Value Setting (dSP02)	Press  &  to modify No. 2 display value (-19999~99999)	99999	
No.3 Display Value Setting (dSP03)	Press  &  to modify No. 3 display value (-19999~99999)	99999	
No.4 Display Value Setting (dSP04)	Press  &  to modify No. 4 display value (-19999~99999)	99999	
No.5 Display Value Setting (dSP05)	Press  &  to modify No. 5 display value (-19999~99999)	99999	
No.6 Display Value Setting (dSP06)	Press  &  to modify No. 6 display value (-19999~99999)	99999	
No.7 Display Value Setting (dSP07)	Press  &  to modify No. 7 display value (-19999~99999)	99999	
No.8 Display Value Setting (dSP08)	Press  &  to modify No. 8 display value (-19999~99999)	99999	
No.9 Display Value Setting (dSP09)	Press  &  to modify No. 9 display value (-19999~99999)	99999	
No.10 Display Value Setting (dSP10)	Press  &  to modify No. 10 display value (-19999~99999)	99999	
No.11 Display Value Setting (dSP11)	Press  &  to modify No. 11 display value (-19999~99999)	99999	
No.12 Display Value Setting (dSP12)	Press  &  to modify No. 12 display value (-19999~99999)	99999	
No.13 Display Value Setting (dSP13)	Press  &  to modify No. 13 display value (-19999~99999)	99999	
No.14 Display Value Setting (dSP14)	Press  &  to modify No. 14 display value (-19999~99999)	99999	
No.15 Display Value Setting (dSP15)	Press  &  to modify No. 15 display value (-19999~99999)	99999	
No.16 Display Value Setting (dSP16)	Press  &  to modify No. 16 display value (-19999~99999)	99999	
No.17 Display Value Setting (dSP17)	Press  &  to modify No. 17 display value (-19999~99999)	99999	
No.18 Display Value Setting (dSP18)	Press  &  to modify No. 18 display value (-19999~99999)	99999	
No.19 Display Value Setting (dSP19)	Press  &  to modify No. 19 display value (-19999~99999)	99999	
No.20 Display Value Setting (dSP20)	Press  &  to modify No. 20 display value (-19999~99999)	99999	

	Display	Descriptions	Default
	20 Points Linearization		
Measuring Status	Present value for measurement Press  &  together for 3 sec		
No.1 Linearization Setting (in01)	1. Input No. 1 scale signal. 2. Press  &  to calibrate input No. 1 scale.	00000	
No.2 Linearization Setting (in02)	1. Input No. 2 scale signal. 2. Press  &  to calibrate input No. 2 scale.	00000	
No.3 Linearization Setting (in03)	1. Input No. 3 scale signal. 2. Press  &  to calibrate input No. 3 scale.	00000	
No.4 Linearization Setting (in04)	1. Input No. 4 scale signal. 2. Press  &  to calibrate input No. 4 scale.	00000	
No.5 Linearization Setting (in05)	1. Input No. 5 scale signal. 2. Press  &  to calibrate input No. 5 scale.	00000	
No.6 Linearization Setting (in06)	1. Input No. 6 scale signal. 2. Press  &  to calibrate input No. 6 scale.	00000	
No.7 Linearization Setting (in07)	1. Input No. 7 scale signal. 2. Press  &  to calibrate input No. 7 scale.	00000	
No.8 Linearization Setting (in08)	1. Input No. 8 scale signal. 2. Press  &  to calibrate input No. 8 scale.	00000	
No.9 Linearization Setting (in09)	1. Input No. 9 scale signal. 2. Press  &  to calibrate input No. 9 scale.	00000	
No.10 Linearization Setting (in10)	1. Input No. 10 scale signal. 2. Press  &  to calibrate input No. 10 scale.	00000	
No.11 Linearization Setting (in11)	1. Input No. 11 scale signal. 2. Press  &  to calibrate input No. 11 scale.	00000	
No.12 Linearization Setting (in12)	1. Input No. 12 scale signal. 2. Press  &  to calibrate input No. 12 scale.	00000	
No.13 Linearization Setting (in13)	1. Input No. 13 scale signal. 2. Press  &  to calibrate input No. 13 scale.	00000	
No.14 Linearization Setting (in14)	1. Input No. 14 scale signal. 2. Press  &  to calibrate input No. 14 scale.	00000	
No.15 Linearization Setting (in15)	1. Input No. 15 scale signal. 2. Press  &  to calibrate input No. 15 scale.	00000	
No.16 Linearization Setting (in16)	1. Input No. 16 scale signal. 2. Press  &  to calibrate input No. 16 scale.	00000	
No.17 Linearization Setting (in17)	1. Input No. 17 scale signal. 2. Press  &  to calibrate input No. 17 scale.	00000	
No.18 Linearization Setting (in18)	1. Input No. 18 scale signal. 2. Press  &  to calibrate input No. 18 scale.	00000	
No.19 Linearization Setting (in19)	1. Input No. 19 scale signal. 2. Press  &  to calibrate input No. 19 scale.	00000	
No.20 Linearization Setting (in20)	1. Input No. 20 scale signal. 2. Press  &  to calibrate input No. 20 scale.	00000	
545	System Setting Page(SYS) Press  &  together for 3 sec		
	1. Finish calibration operating procedures will enter to system setting group. 2. Press  &  together to back to measuring status.		

Warning: Calibration of this meter requires a standard signal with 0.01% accuracy or better and an external meter with 0.005% accuracy or better.