


* Please understand key indicators & functions at the first operation.



FRONT PANEL & KEY FUNCTIONS



Key Name	Symbol	Descriptions
Enter Key & Save Key	ENT	1. In the measuring status, press this key can enter to parameter pages. 2. In the parameter setting, press this key can save the value & go to next parameter.
Shift Key & Alarm Setting Key	AL	1. In the measuring status, press this key for 3 sec can enter to alarm setting page (The selecting digit will be flashed) 2. In the parameter setting, press this key can move the cursor left.
Up Key & Display Value Adjusting Key	↑	1. In the measuring status, press this key for 3 sec can enter to display value adjustment of "ZERO" & "SPAN" 2. In the parameter setting, press this key can increase the digits.
Down Key & A/O Adjusting Key	↓	1. In the measuring status, press this key for 3 sec can enter to analog output adjustment. 2. In the parameter setting, press this key can decrease the digits.

- **1. The following block charts are parameters codes, parameter codes & parameters will alternate flashing if the parameters can be modified.
- 2. To modify the parameters, please press $\leftarrow \uparrow \downarrow \rightarrow$, and press **ENT** to save the parameter after the modification.
- 3. Please don't forget the new pass code after modification.
- 4. In any pages, press \uparrow & \downarrow , or don't press any keys for 2 minutes that will back to measuring status.

PROGRAMMING MODE OPERATING PROCEDURES



Press: ENT ↓ dP-2	Decimal Point 2 Setting (DP-2)	Press \uparrow \downarrow to select decimal point 2(0~3).	0002
Press: ENT ↓ dL-2	Display Low Scale 2 Setting (DL-2)	Press \leftarrow \uparrow \downarrow to modify display low scale 2 for the input signal zero value.(-1999~9999)	0000
Press: ENT ↓ dH-2	Display Hi Scale 2 Setting (DH-2)	Press \leftarrow \uparrow \downarrow to modify display high scale 2 for the input signal zero value.(-1999~9999)	1000
Press: ENT ↓ dP-3	Decimal Point 3 Setting (DP-3)	Press \uparrow \downarrow to select decimal point 3(0~3).	0002
Press: ENT ↓ dL-3	Display Low Scale 3 Setting (DL-3)	Press \leftarrow \uparrow \downarrow to modify display low scale 3 for the input signal zero value.(-1999~9999)	0000
Press: ENT ↓ dH-3	Display Hi Scale 3 Setting (DH-3)	Press \leftarrow \uparrow \downarrow to modify display high scale 3 for the input signal zero value.(-1999~9999)	1000
Press: ENT ↓ dP-4	Decimal Point 4 Setting (DP-4)	Press \uparrow \downarrow to select decimal point 4(0~3).	0002
Press: ENT ↓ dL-4	Display Low Scale 4 Setting (DL-4)	Press \leftarrow \uparrow \downarrow to modify display low scale 4 for the input signal zero value.(-1999~9999)	0000
Press: ENT ↓ dH-4	Display Hi Scale 4 Setting (DH-4)	Press \leftarrow \uparrow \downarrow to modify display high scale 4 for the input signal zero value.(-1999~9999)	1000
Press: ENT ↓ dP-5	Decimal Point 5 Setting (DP-5)	Press \uparrow \downarrow to select decimal point 5(0~3).	0002
Press: ENT ↓ dL-5	Display Low Scale 5 Setting (DL-5)	Press \leftarrow \uparrow \downarrow to modify display low scale 5 for the input signal zero value.(-1999~9999)	0000
Press: ENT ↓ dH-5	Display Hi Scale 5 Setting (DH-5)	Press \leftarrow \uparrow \downarrow to modify display high scale 5 for the input signal zero value.(-1999~9999)	1000
Press: ENT ↓ dP-6	Decimal Point 6 Setting (DP-6)	Press \uparrow \downarrow to select decimal point 6(0~3).	0002
Press: ENT ↓ dL-6	Display Low Scale 6 Setting (DL-6)	Press \leftarrow \uparrow \downarrow to modify display low scale 6 for the input signal zero value.(-1999~9999)	0000
Press: ENT ↓ dH-6	Display Hi Scale 6 Setting (DH-6)	Press \leftarrow \uparrow \downarrow to modify display high scale 6 for the input signal zero value.(-1999~9999)	1000
Press: ENT	RS485 Setting Group Procedures		
Press: ENT ↓ doP	RS485 Setting Page (doP)	The following steps are only available for RS485 type.	
Press: ENT ↓ Addr	Address Setting (Addr)	Press \leftarrow \uparrow \downarrow to modify address (0~255).	0000
Press: ENT ↓ bAUd	Baud Rate Setting (bAUd)	Press \uparrow \downarrow to select baud rate (38400/19200/9600/4800).	1922
Press: ENT ↓ PAri	Parity Setting (PAri)	Press \uparrow \downarrow to select parity (n.8.2/n.8.1/even/odd).	n8.2
Press: ENT			

GENERAL MODE OPERATING PROCEDURES			
Block Charts	Display	Descriptions	Default
Power ON ↓			
10000	Measuring Status	Present value for measurement	
Press: \uparrow for 3 sec ↓ dZ-1	Display Zero 1 Adjustment (dZEro)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the zero value.	0000
Press: ENT ↓ dS-1	Display Span 1 Adjustment (dSPAN)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the span value.	1000
Press: ENT ↓ dZ-2	Display Zero 2 Adjustment (dZEro)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the zero value.	0000
Press: ENT ↓ dS-2	Display Span 2 Adjustment (dSPAN)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the span value.	1000
Press: ENT ↓ dZ-3	Display Zero 3 Adjustment (dZEro)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the zero value.	0000
Press: ENT ↓ dS-3	Display Span 3 Adjustment (dSPAN)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the span value.	1000
Press: ENT ↓ dZ-4	Display Zero 4 Adjustment (dZEro)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the zero value.	0000
Press: ENT ↓ dS-4	Display Span 4 Adjustment (dSPAN)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the span value.	1000
Press: ENT ↓ dZ-5	Display Zero 5 Adjustment (dZEro)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the zero value.	0000
Press: ENT ↓ dS-5	Display Span 5 Adjustment (dSPAN)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the span value.	1000
Press: ENT ↓ dZ-6	Display Zero 6 Adjustment (dZEro)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the zero value.	0000
Press: ENT ↓ dS-6	Display Span 6 Adjustment (dSPAN)	Press \leftarrow to select adjusting speed rate, press \uparrow \downarrow to modify the span value.	1000
Press: ENT	Error Code of Self-Diagnosis		
AdEr	Display	Descriptions	
doFL		Input signal is over 120% of input range or meter error.	
-doFL		Input signal is over display range	
coFL		Input signal is under display range	
-coFL		Cold junction is over sensor's (PT100) measuring range (0~125℃).	
oPEr		Cold junction is under sensor's (PT100) measuring range (0~125℃).	
E-00		Input signal or cold junction is disconnection.	
		EEPROM reading/writing suffers the interference (about 1 million times).	

**Please check the wiring connection is correct first, if the problem still exist, please return the meter to the factory.

Modbus RTU Mode Protocol Address Table

Address	Name	Description	Accept
0000	LOCK	Panel Lock, Input Range 0000-0001(0~1) 0:NO,1:YES	R/W
0001	CH_S	Input Channel Number Select, Input Range 0001-0006(1~6)	R/W
0002	TYPE	Input Range Type, Input Range 0000-000B(0~11) 0:25mV, 1:50mV, 2:0.1V, 3:0.5V, 4:1V, 5:TYPE K, 6:TYPE J, 7:TYPE E, 8:TYPE T, 9:TYPE R, 10:TYPE S, 11:TYPE B	R/W
0003	DP	Thermocouple Decimal Point, Input Range 0000-0001(0~1) 0:10 ⁰ , 1:10 ⁻¹	R/W
0004	UNIT	Temperature Unit, Input Range 0000-0001(0~1) 0:°C, 1:°F	R/W
0005	CJC	Cold Junction Compensation, Input Range 0000-0001(0~1) 0:ON, 1:OFF	R/W
0006	ADDR	Communication Address, Input Range 0000-00FF(0~255)	R/W
0007	BAUD	Baud Rate, Input Range 0000-0004(0~4) 0:38K4, 1:19K2, 2:9600, 3:4800, 4:2400	R/W
0008	PARI	Parity Check, Input Range 0000-0003(0~3) 0:N, 1:E, 2:O, 3:ODD	R/W
0009	AVG	Display Average Times, Input Range 0001-000a(1~10)	R/W
000a	LCUT	Low Cut, Input Range FF9D-0063(-99~99)	R/W
000b	DP_1	Channel 1 Decimal Point, Input Range 0000-0003(0~3) 0:10 ⁰ , 1:10 ⁻¹ , 2:10 ⁻² , 3:10 ⁻³	R/W
000c	DP_2	Channel 2 Decimal Point, Input Range 0000-0003(0~3) 0:10 ⁰ , 1:10 ⁻¹ , 2:10 ⁻² , 3:10 ⁻³	R/W
000d	DP_3	Channel 3 Decimal Point, Input Range 0000-0003(0~3) 0:10 ⁰ , 1:10 ⁻¹ , 2:10 ⁻² , 3:10 ⁻³	R/W
000e	DP_4	Channel 4 Decimal Point, Input Range 0000-0003(0~3) 0:10 ⁰ , 1:10 ⁻¹ , 2:10 ⁻² , 3:10 ⁻³	R/W
000f	DP_5	Channel 5 Decimal Point, Input Range 0000-0003(0~3) 0:10 ⁰ , 1:10 ⁻¹ , 2:10 ⁻² , 3:10 ⁻³	R/W
0010	DP_6	Channel 6 Decimal Point, Input Range 0000-0003(0~3) 0:10 ⁰ , 1:10 ⁻¹ , 2:10 ⁻² , 3:10 ⁻³	R/W
0011	DL_1	Channel 1 Display Low, Input Range F831~270F(-1999~9999)	R/W
0012	DL_2	Channel 2 Display Low, Input Range F831~270F(-1999~9999)	R/W
0013	DL_3	Channel 3 Display Low, Input Range F831~270F(-1999~9999)	R/W
0014	DL_4	Channel 4 Display Low, Input Range F831~270F(-1999~9999)	R/W
0015	DL_5	Channel 5 Display Low, Input Range F831~270F(-1999~9999)	R/W
0016	DL_6	Channel 6 Display Low, Input Range F831~270F(-1999~9999)	R/W
0017	DH_1	Channel 1 Display High, Input Range F831~270F(-1999~9999)	R/W
0018	DH_2	Channel 2 Display High, Input Range F831~270F(-1999~9999)	R/W
0019	DH_3	Channel 3 Display High, Input Range F831~270F(-1999~9999)	R/W
001a	DH_4	Channel 4 Display High, Input Range F831~270F(-1999~9999)	R/W
001b	DH_5	Channel 5 Display High, Input Range F831~270F(-1999~9999)	R/W
001c	DH_6	Channel 6 Display High, Input Range F831~270F(-1999~9999)	R/W
001d	CODE	Pass Code, Input Range 0000~270F(0~9999)	R/W
00ae	DISPLAY1	Channel 1 Normal Display Value, Display Range F831~270F(-1999~9999)	R
00af	DISPLAY2	Channel 2 Normal Display Value, Display Range F831~270F(-1999~9999)	R
00b0	DISPLAY3	Channel 3 Normal Display Value, Display Range F831~270F(-1999~9999)	R
00b1	DISPLAY4	Channel 4 Normal Display Value, Display Range F831~270F(-1999~9999)	R
00b2	DISPLAY5	Channel 5 Normal Display Value, Display Range F831~270F(-1999~9999)	R
00b3	DISPLAY6	Channel 6 Normal Display Value, Display Range F831~270F(-1999~9999)	R