


## KEY FUNCTIONS




## ERROR CODE OF SELF-DIAGNOSIS


|                |                                                                             |
|----------------|-----------------------------------------------------------------------------|
| $\text{LoFL}$  | Input signal is over 120% of input range.                                   |
| $-\text{LoFL}$ | Input signal is under -10% of input range.                                  |
| $\text{RdEr}$  | Input signal is over 180% of input range or meter error.                    |
| $\text{doFL}$  | Input signal is over display range (9999).                                  |
| $-\text{doFL}$ | Input signal is under display range (-9999).                                |
| $\text{E-00}$  | EEPROM reading / writing suffers the interference ( about 1 million times). |

## WIRING CONNECTION


## Compound Input (S01,S02,S03,S04)



## Input Function



## Output Function



## Power

