

30m/s WIND SPEED SENSOR

MANUAL

SPECIFICATION

Communication Interface:

485 communication (modbus) protocol Baud rate: 2400, 4800 (default), 9600

Data bit length: 8 bits Parity mode: None Stop bit length: 1 bit

Default ModBus communication address: 1

Support function code: 03

Parameter settings:

Use the provided configuration software to configure

through the 485 interface

LETTER of AGREEMENT

Basic communication parameters

Code	8-bit binary
Data bit	8-bit
Parity bit	no
Stop bit	1 person
Error checking	CRC (Redundant Cyclic Code)
Baud rate	2400bit/s, 4800bit/s, 9600 bit/s can be set, the factory default is 4800 bit/s

Data frame format definition

Modbus-RTU communication protocol is adopted, the format is as follows:

Initial structure \geq 4 bytes of time

Address code = 1 byte

Function code = 1 byte

Data area = N bytes

Error check = 16-bit CRC

Ending structure ≥ 4 bytes of time

Address code: It is the address of the transmitter, which is unique in the communication network (factory default 0x01).

Function code: The function instruction of the command issued by the host, this transmitter only uses the function code 0x03 (reading register data).

Data area: The data area is the specific communication data. Note that the high byte of the 16bits data comes first!

WIRING CONNECTION

Power:

Brown Power supply (10~30Vdc)

Black Negative power

Communication: Green 485-A Blue 485-B CRC code: two-byte check code. Host inquiry frame structure:

Address code	Function code	Register start address	Register length	Low check bit	Check code high
1byte	1byte	2byte	2byte	1 byte	1byte

Slave response frame structure:

Address code	Function code	Number of valid bytes	Data area	Second data area	Nth data area	Check code
1byte	1byte	1byte	2byte	2byte	2byte	2byte

Register Address

Register address	PLC or configuration address	Content	Operating
0000 H	40001	Instantaneous wind speed 10 times the uploaded data	Read-only