PADDLEWHEEL FLOW SENSOR





■ Accuracy: ±5%; Repeatability: <±1%

■ Measuring range: 0.8~15 Liter/min

■ Thread connection(3/8" NPT), easily installation







SPECIFICATION

ORDER INFORMATION

WIRING CONNECTION

Accuracy: ±5% from scale value
 Repeatability: ±1% from scale value
 Range: 0.8~15 Liter/min

♦ (H₂O at 22°C)

◆ Sensing Principle:
◆ Max. Operating Pressure:
◆ Max. O/P Current (at 24V):
◆ Burst Pressure (at 22°C):
◆ Output Signal:
◆ Operating Temperature:
◆ Power Supply:

Hall-Effect

8 bar

9 bar

Open

Open Collect


0~80°C

2.4~26VDC

♦ Wiring Cable: Round cable3x0.14 mm² LIYY

♦ Protection: IP65

SFL	_52 - <u>Code1</u> - <u>Code2</u>	
Code	Flow range	
2200 0.8~15.0 L/min		
Code2 Wire Length		
N	1.5M	
5	5M	
10	10M	
0	Option	



MATERIAL FEATURES


Materials	POM-Version
Housing	Nylon66
Impeller	POM
Stick of Turbine	SUS304
O-Rings	EPDM
Process Connection	3/8" NPT


K FACTOR TABLE


Flow range (L/min)	Pulse per Liter
0.8~15.0 L/min:	250


INSTALLING NOTE


■ Standard installation diagram according to EN ISO 5167-1 (ID is for inner diameter)














*If can not be suit this situation, please make the calibration of K factor.

■ Installation angle

-Installing in horizontal pipe system







Fig.a: Installation for the pipe without sediment.

Fig.b: Installation for the pipe without bubble and must be full.

Fig.c: The best installation position can avoid the influences of sediment and bubble.

-Installing in vertical pipe system

It can be installed at any angle, the better installation flow direction is from bottom to top.

■ Installation Precautions

